

ASSEMBLY INSTRUCTION

TL8098



A	B	C	D
			
6 PCS	1 PC	1 PC	3 PCS





FIG.
1



ASSEMBLY INSTRUCTION

TL8098



A	B	C	D
			
6 PCS	1 PC	1 PC	3 PCS





FIG.
2



ASSEMBLY INSTRUCTION

TL8098



A	B	C	D
			
6 PCS	1 PC	1 PC	3 PCS




FIG.
3

